

Betriebstemperaturen Heizstrahler	Operating temperatures infrared heaters
<ul style="list-style-type: none"> • Kurzwellenstrahler: Innentemperatur von 1.800-1.900°C. Das Glas der Röhre wird 800 - 900°C heiß. • NO GLARE Keramikstrahler erreichen Innentemperaturen um die 600°C. 	<ul style="list-style-type: none"> • Our short-wave heaters have a temperature between 1.800-1.900°C. The glass of the tube has a temperature between 800 - 900°C. • NO GLARE ceramic heaters reach temperatures up to 600°C.
Oberflächentemperaturen Gehäuse Heizstrahler	Surface temperatures housing infrared heater
<p>TERM2000: 160 bis 170°Celsius SMART: ca. 105°Celsius HEATPANELS: ca. 95° C</p>	<p>TERM2000: 160 to 170°Celsius SMART: about 105°Celsius HEATPANELS: about 95° C</p>